
SLINGING LOADS

Connect the hitch as planned. Test it an inch off the ground.

Rev 01 Effective 2026-09-01 Review 2027-09-01 Printed copy uncontrolled

PURPOSE

Put the sling on the load so the tension goes where you calculated.

SCOPE

Making hitches on construction and industrial lifts this program covers.

This document is the method - the steps. Hazards and residual risk for the same work are in the JHA library. A procedure is not a hazard analysis.

PROCEDURE

01 STABLE PIECE

Block or shore so the load cannot roll onto the rigger.

02 POINTS

Designed lifting points. If none, the method is engineered or it is not a hitch this program allows.

03 APPLY THE HITCH

No twists, no knots, no choke off a guess. Softeners on edges.

04 HARDWARE

Pins in. Latches working. Shackles used as designed.

05 CLEAR AND TEST

Hands off. Zone held. Inch off the ground. Re-rig if it tilts, slips or shocks.

RESPONSIBILITIES

THIS PROGRAM

The published method for the work. Stop-work is named in it. It does not own the site.

SUPERVISOR

Confirms the plan, the crew, the zone and the stop criteria. Owns whether the hook moves.

CRANE OPERATOR

Runs only the machine they are competent on, to the chart, after inspection. Stops on an unclear signal or a broken plan.

RIGGER

Selects, inspects and applies the hitch. Does not guess weight, centre of gravity or angle.

SIGNALPERSON

One set of hands on the crane. Holds the zone. STOP means stop.

WORKER

Works to this program and to site rules - whichever is stricter. Uses the three rights. Reports damaged gear.

REQUIRED COMPETENCY

Rigger

Can explain the hitch they are about to make

EQUIPMENT

Selected slings and hardware
Softeners
Tag lines

PPE

Hard hat
CSA-grade footwear
High-visibility clothing
Eye protection
Task-rated gloves
Hearing protection where required
Fall protection where the work exposes a fall

PROHIBITED PRACTICES

Wrapping a sling around a hook as a makeshift eye
Riding the load to "balance it"
Hands on a live sling

EMERGENCY RESPONSE

Stop the lift. Make people safe. Land or hold the load if it can be done without a second incident. First aid. Notify the site and the employer. Hold the scene.

DOCUMENTATION

FLHA
Pre-use / inspection record
This SWP number and revision

REFERENCES

Workers Compensation Act s. 21 - known or reasonably foreseeable hazards; instruction and supervision
OHS Regulation (B.C. Reg. 296/97, in force 15 Apr 1998) Part 3 - OHS program, instruction, inspections
OHS Regulation Part 4 s. 4.13 - risk assessment where rescue or evacuation may arise
OHS Regulation Part 8 - PPE; headwear CSA Z94.1-05 or Z94.1-15
OHS Regulation Part 11 - fall protection
OHS Regulation Part 14 - Cranes and Hoists
14.2(5) - CSA Z150-1998, or ASME B30.5-2004, or ASME B30.22-2005 (articulating boom)
14.2(6) - CSA Z248-2004 for tower, hammerhead and self-erecting tower cranes
14.35 pre-use inspection 14.36 load weight 14.42.1 critical lift 14.44 loads over work areas 14.45 unattended loads
14.47-14.49 signals
OHS Regulation Part 15 - Rigging
Manufacturer load chart, manual and configuration limits
Site lift plan, FLHA and site rules where stricter