

RIGGING

Know the load. Know the hitch. Protect the sling. No people under the load.

Working copy. Current controlled version is on this site.

RATED GEAR

Slings and hardware are identified, inspected and used within WLL, including angle and hitch derates. ASME B30.9 as named in Part 15.

NO GUESS

Weight and centre of gravity are confirmed. Sling angle is calculated when it matters. Below 30 deg from horizontal is not a hitch this program allows unless an engineer owns the numbers.

OUT OF SERVICE

Damaged rigging is tagged, isolated and reported. No "one more lift."