

LOADING PLATFORM

This deck. This floor. This serial. Empty. Not last floor's sheet.

Rev 01 Effective 2026-09-01 Review 2027-09-01 Printed copy uncontrolled

WHEN

Every loading-platform install, reposition or strike the crane hooks. Critical lift. Fill PROVEN-FRM-053. Daily SuperDeck extend / retract is not this sheet.

PURPOSE

Name the facts the SWP cannot know until this morning: manufacturer, serial, dead weight, WLL, pick points, chain, wind number, named crew, holds. The method stays PROVEN-SWP-030. If this sheet contradicts the SWP, stop and fix one of them before the hook moves.

An SJP is not a longer SWP. It is the SWP plus the facts of this job. Do the work to the method. Fill this instance. If they disagree, stop.

BUILT ON

SWP - LOADING PLATFORM - PROVEN-SWP-030 -> <https://sin.ae.org/safety/swp/loading-platform-reposition>

JHA - LOADING PLATFORM - PROVEN-JHA-014 -> <https://sin.ae.org/safety/jha/loading-platform-reposition>

SWP - CRITICAL LIFTS - PROVEN-SWP-019 -> <https://sin.ae.org/safety/swp/critical-lifts>

FILL THIS DECK - PROVEN-FRM-053 -> <https://sin.ae.org/safety/form/loading-platform-sjp>

FACTS THIS SHEET MUST NAME

Project, building, floor leaving, floor landing
 Manufacturer / system - Doka, SuperDeck, CantiDeck, PERI RCS MP, DOC, other
 Serial / ID. Type plate. Fixed or retractable - said
 OEM user information at the lift - document number if it has one
 Dead weight empty, plus rigging (14.36). Not the service WLL
 Service WLL / remaining WLL - named so nobody flies it
 Every designated pick point, named. Four unless this OEM names otherwise
 Chain / sling type, WLL, length. Doka: 4-part 3.20 m, <= 30 deg if that is this serial
 Wind limit - the lower of crane, manufacturer, this SJP. A number. Doka cites 72 km/h
 Tag lines - how many, who holds them
 Radio channel. Confirmation loop
 Exclusion below and at the slab edge (Part 11, 14.44)
 Who releases props / clamps. Who says landed

HOLD POINTS

01 GATE

User information and type plate at the lift. Empty dead weight known. FRM-053 filled. Brief done. If not, the hook does not take the deck.

02 HITCH AND EMPTY

Four designated points. Chain as the OEM. People off. Material off. Tag lines on.

03 RELEASE

Host has released props / clamps. Confirm free. Then hoist.

04 LAND

Host pins rails and props, clamps or anchors as the OEM. Supervisor says landed. Then disconnect.

ABORT

User information or type plate not at the lift
Anyone treating service WLL as the fly weight
People or material on the deck
Props still in
Improvised picks
Wind above the number on this sheet
Asked to retract or extend a SuperDeck with the crane
The work is being asked to drift from PROVEN-SWP-030

NAMED ON THE SHEET

Operator
Rigger
Signalperson
Tag-line hands
Platform supervisor (host)
Prime contact
Lift supervisor

DOCUMENTATION

This SJP / PROVEN-FRM-053
PROVEN-FRM-007
PROVEN-FRM-009
FLHA
OEM user information cited

REFERENCES

Workers Compensation Act s. 21 - known or reasonably foreseeable hazards; instruction and supervision
OHS Regulation (B.C. Reg. 296/97, in force 15 Apr 1998) Part 3 - OHS program, instruction, inspections
OHS Regulation Part 4 s. 4.13 - risk assessment where rescue or evacuation may arise
OHS Regulation Part 8 - PPE; headwear CSA Z94.1-05 or Z94.1-15
OHS Regulation Part 11 - fall protection
OHS Regulation Part 14 - Cranes and Hoists
14.2(5) - CSA Z150-1998, or ASME B30.5-2004, or ASME B30.22-2005 (articulating boom)
14.2(6) - CSA Z248-2004 for tower, hammerhead and self-erecting tower cranes
14.35 pre-use inspection 14.36 load weight 14.42.1 critical lift 14.44 loads over work areas 14.45 unattended loads
14.47-14.49 signals
OHS Regulation Part 15 - Rigging
Manufacturer load chart, manual and configuration limits
Site lift plan, FLHA and site rules where stricter
Doka loading platform User Information - four welded lifting points, Doka 4-part chain 3.20 m, empty only, no persons, sling angle ≤ 30 deg, reposition wind 72 km/h, one platform at a time.
Conquip CantiDeck User Guide - four lifting points, 4-leg chain, tag lines opposite corners, do not lift until props are released, disconnect after screw jacks tight, WLL on the type plate.
Preston SuperDeck - retractable drawer. Install is a licensed crane lift. Daily extend / retract is host operation. No crane licence to roll it. 604 817 DECK.
PERI RCS MP material platform - crane-set. Anchors or MULTIPROP between slabs. Host. User information for this serial.
DOC loading platform - powered retractable drawer. Install / relocate by crane. Daily extend / retract is host, including the 110 V supply.
14.36 load weight 14.44 loads over work areas 14.47-14.49 signals Part 11 at the slab edge
Manufacturer user information for this serial at the lift. Pick points only as the OEM names. Fly weight is empty dead weight plus rigging - not the service WLL.